


## Connection Diagram



## Features

- Input Voltage AC 110 V - 240 V
- Inbuilt surge protection circuit
- Output Voltage DC 12V
- Output Current load upto 5 Amps
- Output Voltage can be adjusted if the wiring distance is more to avoid DC Voltage drop
- Output Voltage & Overload Protection
- Enclosure designed to accomodate Battery ( Lead Acid Type )
- Inbuilt battery management

### ⚠ CAUTION ⚠

To be serviced by authorized technicians. Product should not be installed in wet or damp conditions

### ⚠ DANGER ⚠

To avoid risk of electric shock, turn off AC power before installing or servicing AFS0500 power supply